143.00 mm

210.00 mm

Fridge Speaker Function

Model **HUS-BC70-BTS**

Basics

- Unit accepts Blue Tooth Connection, USB and MicroSD card.
- File types supported are MP3, WMA, WAV & FLAC.

CONTROLS

POWER button

Turn on - Short Press (1sec) to turn the speaker on. Circle will glow SOLID WHITE in standby mode.
Turn off - Press and hold for 3-4 seconds. When off, the circle will no longer light up.

MODE button

Basics - Short Press (1sec) will switch the speaker between any available modes

Bluetooth Mode

To switch from Standby mode to Bluetooth mode, short press(1sec) the mode button.
Circle on power button will now *FLASH* BLUE slowly, until connected.

Bluetooth Connection

To connect your Bluetooth player, search for **'FROTHY'** as the device, and pair.
Circle on the power button will glow SOLID BLUE, and speaker will beep once, when connected.
Speaker will now automatically connect each time it is turned on, and Bluetooth mode is selected.

USB Mode

When a USB drive is inserted, the speaker will automatically switch to USB Mode.
Circle on power button will glow SOLID ORANGE when in USB mode.
Alternatively, if a USB drive is already installed, short press mode button until USB mode is selected

IMPORTANT NOTE: USB Mode does NOT support playback via phone/device when connected by USB cable. However the USB port is powered, so will charge your phone or device when connected.

MicroSD Mode

When a MicroSD drive is inserted, the speaker will automatically switch to MicroSD Mode.
Circle on power button will glow SOLID GREEN when in MicroSD mode.
Alternatively, if a MicroSD drive is already installed, short press mode button until MicroSD mode is selected.

IMPORTANT NOTE: Mode will not change from Bluetooth, if a USB and/or MicroSD are not inserted.

PLAY/PAUSE button

Short press (1sec) to play or pause the music.
IMPORTANT NOTE: A long 3-4 second press will UNPAIR Bluetooth mode.

VOLUME UP and VOLUME DOWN buttons

Short press or tap to turn volume up or down as desired.
Long press and hold will also change volume.
IMPORTANT NOTE: Speaker will beep once maximum volume has been reached.

NEXT SONG and PREVIOUS SONG buttons

Short press or tap, to select previous or next track/song as desired.

客户名称：GB澳大利亚

技术要求

1.材质105g双铜

2.彩色印刷

绘 图	
底图总号	
本型号底图号	
版本号	

标记	处数	更改文件号	更改内容	签 名	日 期

标记	处数	更改文件号	签 名	日 期	材料		广东哈士奇制冷科技股份有限公司
					共 张	重 量	比 例
设 计	林嘉勇	会 签					BC-70-MX-C
制 图		标准化			标 记	第 张	说明书插页
审 核		标 准			图形识别符号		
工 艺		日 期	20240625				BC70MXCGBAU0401A