


Fridge Operation Manual


Model: HUS-BC70RET



Bar Fridge Basic Instructions

Model: HUS-BC70RET

1. Unit is ready to plug in
2. Thermostat temperature control and the LIGHT on/off switch is located at rear of unit, see pic following.



-**Thermostat control** - alter using flat head screwdriver or similar. Position 5 is coldest (*Note this can freeze product)

3. There are different shelving positions.
4. For warranty enquiries and claims please email Vicservice@bar-fridges-australia.com.au
5. Things you need to know;
 - a. Unit is Sub Tropical rated, so it can work in high ambient temperatures but not in direct sunlight.
 - b. Unit has 'timer defrost' meaning it will go into defrost for 20minutes every 4 hours.
 - c. Unit is compressor driven and you will hear this running if near the fridge.
 - d. Unit has refrigeration gas running through piping, this sounds like 'gurgling' and is normal operation.
 - e. Do not place in direct sunlight or build in behind a cupboard door.
 - f. Door on standard HUS-BC70RET is not 'self-closing', so ensure door gets closed when used.

Specifications


Model	HUS-BC70RET
Climatic class	ST (Sub Tropical)
Storage Temperature (°C)	0>10 (38oC Ambient)
Anti-shock protection class	I
Capacity (L)	70
Rated Voltage (V)	AC220/240V
Rated Frequency (Hz)	50/60Hz
Watts	85
Power consumption:(KWh/24h)	0.65
Refrigerant/Charging (g)	R600a/17g

Set up and Positioning

- After unpacking dispose of rubbish sensibly
- When moving the fridge avoid hard jolts and bumps
- Don't carry fridge holding the door, always carry using body of fridge or use trolley
- Upon setting up fridge into your position ensure it is square and level, use feet adjustments where needed
- Do not position near sources of heat, like ovens and dishwashers
- Do not position in direct sunlight
- Do not move or tilt while in operation
- Allow as much ventilation wherever and whenever you can, the more ventilation the more economical the fridge will run and the longer the compressor life you will get
- Ensure your electrical lead hasn't been damaged, if you see any fault or cut in the power lead refer to electrician before plugging in
- Once in position allow 30minutes and turn "ON"

Safety

- Do not pull plug directly from socket without turning 'OFF' first
- Do not try to access unit electrics unless authorized to do so and unless unit is "OFF" and "UNPLUGGED"
- Do not have items near unit that could be damaged by heat, the condenser coils are located in the walls so these get quite warm (40oC) during normal operation
- Do not rest heavy items (including the fridge) on the electrical lead
- Queensland** installation/servicing requirement: Needs a Gas Repair Job (hydrocarbon refrigerants) if the appliance gas system is being opened or charged. Authorised technician needed.



Not to be used for preservation of Fresh Foods, this is a drinks fridge.

Storage inside the cabinet

- It is not recommended to store blood or special pharmaceuticals in the fridge
- Keep drinks at least 1cm away from walls to allow air flow and to stop bottles freezing on back wall close to 'cold-plate'.

Trouble Shooting / Basic Info

There are basic things you need to look and check before trying to initiate a technician call out for warranty circumstances.

Noise

If your unit has become noisy, please check the following;

- Can you ascertain exactly where the noise is coming from? It may be a loose screw or part of the fridge that is now vibrating and is easy to fix.
- Is the compressor / fridge level, a compressor not level will make a 'clunking' noise on start-up and shut down.
- Does the fan sound noisy? It may be as simple as needing slight adjustment.

Not Cooling

So all of a sudden unit has stopped cooling.

- Does the compressor run? Make sure compressor is running, if it is running, thermostat is on 5, and you have a warm fridge then there is a gas problem and technician will be needed.
- Check fan inside unit (if applicable). If fan inside unit is not working then air won't be being distributed evenly, a lot of areas will not be as cold as some, and rear plate may ice up.
- Have you got the thermostat set correct? Or has it been altered, remember the higher the number you set this on the colder the fridge will be.
- Is your door sealing properly, check all the way around door seal to make sure it is seating correct on fridge body, small gaps won't affect cooling.

Freezing Product.

- The units are not freezers but there is a possibility of freezing drinks, especially if unit is set on the highest setting of 5 or drinks are placed within 1cm of back cold-plate within the fridge.
- If you are experiencing rapid ice buildup on inside rear cold plate of unit the thermostat is likely to be faulty, technician is needed.

Maintenance

- Clean door seal every 6 months, use eucalyptus oil and a soft cloth
- Clean inside unit every 6 months as water parts and food can cause mold and bacteria may form, Bi carbonate soda works well.
- Clean underneath unit periodically

WARRANTY - Contact – PH: 1300 170640 with your Serial Number, Purchase Invoice Number and Fridge Model details for warranty queries.