



INSTRUCTION MANUAL

Model: BD113-B / BD113-SS

This manual contains important information including safety and installation instructions of the appliances. Please read it carefully and keep handy for easy reference.

CONTENTS

IMPORTANT SAFETY INFORMATION.....	P.2
ACCESSORY INSTALLATION BEFORE OPERATING.....	P.4
REVERSE THE DOOR SWING.....	P.4
OPERATING THE FREEZER.....	P.5
CARE AND MAINTENANCE.....	P.6
TROUBLESHOOTING.....	P.7
WARRANTY STATEMENT.....	P.8-9

IMPORTANT SAFETY INFORMATION

- Read all instructions before using the appliance.
- It is hazardous for anyone other than an authorized Service Person to carry out servicing or repairs to this appliance, the gas is flammable.
- Take serious care when handling, moving, and using the appliance to avoid either damaging the refrigerant tubing or increasing the risk of a leak.
- Replacing component parts and servicing shall be done by BFA authorized service technicians so as to minimize the risk of possible ignition due to incorrect parts or improper service.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
 - Do not rest heavy items (including the fridge) on the electrical lead.
 - Queensland** installation/servicing requirement: Need qualified technician to perform a Gas Repair Job (hydrocarbon refrigerants) if the appliance gas system is being opened or needs to be charged.



- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Do not kink or pinch the power supply cord of the appliance.
- **WARNING:** Keep ventilation openings in the appliance enclosure or in the built-in structure, clear of obstruction. Unit 'breathes' from the front, so you must leave the front bottom grill clear.
- This appliance is intended to be used for purpose of drinks only, it is not recommended to store fresh food, blood, medicine or vaccines in this appliance.
- Plug into a grounded 3-prong outlet. Do not remove grounding prong, do not use an adapter, and do not use an extension cord.
- You can clean appliance with lemon juice concentrate and warm water, followed by wipe down with clean cloth. Unit must be turned OFF while cleaning process takes place
- Do not connect or disconnect the electric plug when your hands are wet.
- Do not attempt to repair or replace any part of your appliance unless it is specifically recommended in this manual. All other servicing should be referred to a qualified technician, contact Bar Fridges Australia to assist.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance. The fumes can create a fire hazard or explosion.
- Use two or more people to move/install the refrigerator. Failure to do so can result in back or other injury as units are extremely heavy.
- To ensure proper ventilation for your appliance, the front of the unit must be completely unobstructed. This unit must be installed in an area protected from the elements, such as wind, sun, rain, water spray or drips.
- The appliance must be installed with all electrical connections in accordance with state and local codes. A standard electrical 10Amp supply (220-240V AC 50 Hz).

- It is important for the appliance to be leveled in order to work properly. You may need to make several adjustments to level it using the adjustable feet provided.
- Although the unit has been tested at the factory, due to transit and storage, you should clean the appliance before use.
- Do not use solvent-based cleaning agents or abrasives on the interior. These cleaners may damage or discolor the interior.
- This unit can be used indoors and in covered alfresco enclosed area's.
- This appliance is CFC and HFC free and contains small quantities of Isobutane which is environmentally friendly, but flammable. It does not damage the ozone layer, nor does it increase the greenhouse effect. Care must be taken during transportation and setting up of the appliance that no parts of the cooling system are damaged. Leaking coolant can ignite and may damage the eyes.
- In the event of any damage:
 - Avoid open flames and anything that creates a spark,
 - Disconnect from the electrical power line,
 - Air the room in which the appliance is located for several minutes, and
 - Contact Bar Fridges Australia to arrange service.
-  The recycle symbol on the product or its packaging indicates that this product is not to be handled as normal household waste and it is to be taken to a recycling collection point for electrical and electronic goods.
- **IMPORTANT NOTE:** Freezers that have been tilted **MUST** remain in the upright position for 24 hours prior to plugging it in.
- The freezer is 'built in style' so they can install in a wall cavity, front grill must be clear.
- Keep away from heat sources, such as radiators or air conditioning pipes.
- Allow free air circulation to the refrigerator unit if you have option, this can help lessen run times.
- The installation instructions furnished with the device indicate a clearance of min 20mm at top, 100mm at the rear and min 20mm at each side.
- **WARNING:** When positioning the appliance, ensure the supply cord is not trapped or damaged.
- **WARNING:** Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

ACCESSORY INSTALLATION BEFORE OPERATING

UNPACKING AND CLEANING THE APPLIANCE

- Remove the exterior and interior packing materials.
- Let the appliance stand upright for approximately 2 hours before connecting it to the power source, which helps to reduce the possibility of a cooling-system malfunction from handling during transportation.
- Use a soft cloth to clean the interior surface with lukewarm water.
- Install the door handle provided with the appliance.
- This appliance is designed for free standing or built-in (fully recessed) installation.
- This appliance is intended to be installed in a space between two units.
 1. If product height is 800mm, the minimum space should be 615mm wide × 630mm deep × 810mm high.
 2. If product height is 860mm, the minimum space should be 615mm wide × 630mm deep × 870mm high.

Please note: When the product is installed, there should be a small ventilation gap between the top of the unit and the underside of any fitting above (6mm or 1/4").

LOCK & UNLOCK THE DOOR (FOR OPTION)

- Lock is fitted and key is attached in packing with this Manual.
- Insert the key into the lock and turn it counter-clockwise to unlock the door. To lock it, please follow the reversed operation. Please keep the key in safe location.

Installation of the Handle

To install the handle, please follow these instructions:

- Carefully pull the door gasket (seal) away from the door in the area where the handle will be attached.
- Place the handle over the screw holes on the outside of the door and attach it with the screws that have been provided. Tighten the screws.
- Press the door gasket back into its groove.

REVERSING THE DOOR SWING

This appliance has the capability of the door opening from either the left or right side. The unit is delivered to you with the door opening from the left side. Should you desire to reverse the opening direction, please follow the instructions below:

1. Carefully lay the appliance on its back. Use cushioning to protect the floor and appliance.
2. Using a Philips screwdriver, remove the two screws and bottom right hinge beneath the door. Keep the hinge in a safe place in case you need to reverse the door again in the future.
3. Carefully slide the door off and place it on a padded surface.
4. Remove the bottom support bracket from the right side.
5. Remove the top right hinge and keep in a safe place in case you want to reverse the door in the future.
6. Remove the screws from the top left and transfer to the right.
7. Install the top left hinge.
8. Install the bottom left hinge to the door. Do not over-tighten the screw.
9. Rotate the door 180° and relocate it on the top hinge.
10. Install the bottom support bracket.
11. Adjust door alignment. When set, tighten screw on hinge.


Please note: Keep the spare hinge plate(s) to be able to reverse the door back again.

OPERATION

- The appliance should be placed where the 'ambient' temperature is between 10~38°C.
- To prevent damaging the door gasket, make sure to have the door opened fully all the way before pulling the shelves out.

Led Display Of Schmick Controller

Interface



Explanation of the icons

Icons	Explanation
	Refrigeration LED: During refrigeration, the LED is on; When the cold room temp. is constant, the LED is off; During the delay process, the LED flashes.
	Defrost LED: During defrosting, the LED is on; During the delay display after defrost, the LED flashes.

Explanation of the buttons

Buttons	Explanation
 	Set temperature (compressor stop temperature) adjustment. ● Press button, the set temperature is displayed. ● Press or button to modify and store the displayed value. Press button to exit the adjustment and display the cold room temperature. ● If no more button is pressed within 10 seconds, the cold room temperature will be displayed.
	● Manual start/stop defrost: Press button and hold for 6 seconds to defrost or stop defrost.

CARE AND MAINTENANCE

CLEANING THE APPLIANCE

- Turn off the power, unplug the appliance, and remove all items including shelves.
- Wipe the inside surfaces with a sponge and baking soda solution. The solution should be about 2 tablespoons of baking soda to 1 litre of warm water.
- Wash the shelves with a mild detergent solution. Allow wooden shelves to dry before placing back into the wine cooler.
- Wring excess water out of the sponge or cloth when cleaning area of the controls, or any electrical parts.
- Wipe the outside cabinet with warm water and mild liquid detergent. Dry with a clean soft cloth.
- Do not use steel wool or steel brush on the stainless steel. These will contaminate the stainless steel with steel particles and rusting may occur. Olive Oil is great to run on stainless for protection against rust.

POWER FAILURE

Most power failures are corrected within a few hours and should not affect the temperature of your appliance too much that it spoils drinks. If the power is going to be off for a longer period of time, you need to take the proper steps to protect your contents.

MOVING THE APPLIANCE

- Remove all items.
- Securely tape down all loose items (shelves) inside your appliance.
- Turn the adjustable leg up to the base to avoid damage.
- Tape the door shut.
- Be sure the appliance stays secure in the upright position during transportation. Also protect outside of appliance with a blanket, or similar item.

ENERGY SAVING TIPS

- The appliance should be located away from heat producing appliances, and away from direct sunlight.
- Ensure that the unit is adequately ventilated. Never cover air vents at front.
- Only open the door when necessary. Avoid leaving the door open for long periods or opening/closing the door frequently.
- For beer units, when you are away, set at 8-10°C, this means much less energy consumption and still will keep beverages from spoiling
- Keep unit at least $\frac{3}{4}$ full, this will ensure less run times, as less air to chill
- Every 12 months or so check your rear wire condenser (behind panel) for dust and particle build up, this can cause over running and overheating if blocked. Clean with brush or vacuum up the build-up of dust/particles.

TROUBLESHOOTING

If you feel the appliance is out of order, follow these instructions to try to see if you can solve the problem simply by yourself before calling for service.

PROBLEM	POSSIBLE CAUSE / MEASURE
The appliance does not operate.	• Not plugged in. • The appliance is turned off. • The circuit breaker tripped or a blown fuse.
The appliance is not cold enough.	• Check the temperature control setting. • External environment may require a higher setting. • The door is opened too frequently. • The door is not closed completely. • The door gasket does not seal properly.
Automatically turn-on and turn-off frequently.	• The room temperature is hotter than normal. • A large amount of contents has been added to the Wine Cooler. • The door is opened too frequently. The door is not closed completely. • The temperature control is not set correctly. The door gasket does not seal properly.
The lighting does not work.	• Not plugged in. • The circuit breaker tripped or a blown fuse. The lighting is turned off.
Too much vibration	• Check to assure that the appliance is level. • Check to assure no parts inside the cabinet or in the compressor chamber are loose.
The unit seems to make too much noise	• The rattling noise may come from the flow of the refrigerant, which is normal, can sound like water trickling (gurgling). • As each cycle ends, you may hear 'gurgling' sounds caused by the flow of refrigerant. • The appliance is not level.
The door will not close properly.	• The unit is not level. • The door was reversed and not properly installed. • The gasket is dirty, or cold and out of shape. • The shelves are out of position.
Display "HH".	• The room sensor is short-circuited. • The temperature overheated (more than 99°C/210°F).
Display "LL".	• The room sensor is open-circuited. • The temperature is too low (less than -45°C/-49°F).

All refrigerated compressor driven products purchased from Bar Fridges Australia (BFA) are covered by our exclusive **'Product Confidence'** warranty;

***Products purchased OVER \$600, 2 Years Australia Wide 'On Site' parts and Labor Warranty** strictly from the invoice purchase date. This is **NOT** 'parts only' or 'back to base', this is real warranty no cost to you.

***Exceptions:** Scratch 'n' Dent and items on special (see below) and any application where products other than drinks are used for cold storage.

***Products purchased UNDER \$600: 1 Year Australia Wide 'New Replacement' Warranty** from the invoice purchase date will be replaced with new, depending on location and logistics.

*The warranty has been stream-lined in May 2017 to include commercial and domestic under one umbrella.

***Exceptions:** Scratch 'n' Dent and items on special (see below) and any application where products other than drinks are used for cold storage.

All **Scratch 'N' Dent bargains and Sales I Specials** where stock is reduced in price have separate warranty terms which are stipulated on both the website listing and the invoice. These units are deemed to be second hand and are discounted accordingly - their warranty periods are also reduced.

BFA will pay all costs to repair, replace (with similar or equivalent model) or refund (at our sole discretion) for any faulty unit or part thereof should the fault be deemed as a defect in operation, material, or workmanship. BFA is geared towards fairness in all cases. In most instances when we recognize a problem and the problem can be remedied on-site, the work is undertaken via our fleet of service technicians. Should it prove difficult to diagnose the fault or perform the repair work in the space or environment provided, or if the unit is located outside the BFA service area then the unit will need to go off site for repair and return.

Warranty Does Not Include;

- Any expenses resulting from service calls for either products or faults that are not specifically covered by this warranty, (including units which are found to be operating normally). All call out fees will then be borne by the client (at our discretion).
- Any expenses resulting from service calls for both fault diagnosis and repair after the above warranty terms have expired. BFA will always attempt to assist after warranty periods have expired with spare parts and service, just as we would within warranty periods. Glass door fridges are more prone to needing maintenance than domestic units do.
- Any client wishing to return a purchased unit with no legitimate reason. It is understood that the client has read our listing and knows all of the specifications in regards to size, noise levels, condensation, power consumption and the correct environment suited for the fridge. The cost to return is fully borne by the client as well as the initial cost of the delivery, plus a re-stocking fee of 10%. This strictly applies for a 14 day period from the date of the delivery.
- Any expenses resulting from defects to the unit caused by any person, other than BFA or its authorized service agents, including;
 - a) Incorrect installation - such as a lack of ventilation, exposure to the elements where it 's not part of the refrigerator specification, sunlight in particular.
 - b) Abuse, misuse or alteration.
 - c) Failure to let compressor oil and/or refrigerant settle after relocation.
 - d) Damage during movement by the client from one location to another including lifting the unit by the doors or door handles.
 - e) Act of god or his son, or aliens invading earth.
 - f) Insect and/or vermin infestation.
 - g) Electrical/Power surges and/or storm damage.
 - h) Damage to any area or structure due to movement of the fridge, like wooden floors, walls and glass etc.
 - i) Faults due to client re programming or setting controllers wrong.
 - j) Blocked condensers due to not being cleaned, it is up to customer to ensure condensers are cleaned periodically, see www.cleanme.eu for relevant info on the type of units that need this.

- Any indirect, incidental or consequential damages, spoilt wine or frozen/exploded drinks, water damage including condensation forming on outer glass etc., except as provided for by ACL, Australian Consumer Law.
- Units used in 'moveable' vehicles (Cars, Vans, Buses etc.) will not be covered under any warranty at all. Talk to us about specific applications and we can help with recommendations.
- Fridges that do not come under our standard warranted lines, these will be clearly advertised with the warranty information directly pertaining to that product, and the purchase invoice will state the warranty.
- Fluorescent or LED lights, locks, ballast, rusted parts (including Stainless Steel), screws, nuts, and any plastic parts involving basic wear and tear.
- Labour if the technician has to travel outside of BFA's service area, or the mainland of Australia.
- Freight costs for repair if unit is outside the Bar Fridges Australia service agent areas, all major capital cities and towns are included but there are some rare remote areas we cannot service.
- Compensation/Claim in any form if the client hasn't read the listing correctly in regard to the fridge power draw, operation and noise levels. BFA has extensive product details and the consumer is obligated to make an informed decision based on our listings and large amounts of information available.

How to Obtain Service:

For assistance, there are 3 ways below, to help we require **fridge model, serial number, date of purchase and a description of the problem**, please ensure you have as much info as possible to speed up process, a picture of the fridge showing wide shot and also the controller (if applicable)

1. Go online at <https://www.bar-fridges-australia.com.au/making-a-warranty-claim.html> - This will take you through the basics questions needed for us to assist in a timely manner.
2. Email service department directly on vicservice@bar-fridges-australia.com.au
3. Contact BFA Service Division direct on 1300 376849 Ext2, 8:30am > 4:30pm Mon-Fri.

There is **no guaranteed time limit for repairs** to be carried out due to the nature of refrigeration products and the technician time booking constraints, you must **allow 7-14 days** as a fair down time, refrigeration mechanics these days are very busy and jobs have to be booked in advance. Sometimes units will need to be arranged for return and repair, which can be time consuming. In saying all this, all warranty issues are regarded as 'urgent', and every effort will be made to have the problem rectified immediately.

In some cases, to speed the process up where a job is considered a minor repair, the parts may be sent direct to the client and authorization will be given to make the repair themselves with the warranty not being voided. This is popular in situations like fan replacements, which are easy to swap, when the client is an actual tradesman or handy with a screwdriver. We will never allow electrical wiring jobs without tech, only plug 'n' play style jobs.

Proof of Purchase:

We have made proof of purchase not a mandatory thing, but of course it will help. When purchased we internally register the model and your details so to find details we need invoice (as we keep serial numbers) or either email address or phone number that you lodged at the time.

Authorized Service Agents:

Service is provided by BFA and its' authorized service network of refrigeration mechanics Australia Wide. We attempt to cover all areas though certain remote areas can often translate to longer waiting periods. We don't allow for services outside of normal working hours, otherwise call out fees are applicable. ALL call outs have to be arranged and performed by approved BFA service technicians. Clients cannot arrange their own technicians within warranty period at all, this could void the warranty.

Replacement Parts / Items Out Of Warranty:

Parts will always be available at very reasonable prices after the warranty period is finished, our exclusive 10year parts availability guarantee is great piece of mind. It is very important to BFA to keep clients happy after the warranty period has expired. The following link allows you to lodge a claim/parts request, so add as much info as you can and we will assist.

<https://www.bar-fridges-australia.com.au/making-a-warranty-claim.html>

*Check our unique Fridge Diagnosis Knowledge Base To Assist In Finding Fault.

<http://kb.bar-fridges-australia.com.au/>

40Production Drive, Alfredton, VIC 3350 Ph: 1300 376849 Ext2
Email: vicservice@bar-fridges-australia.com.au www.bar-fridges-australia.com.au